# AMWPD-W


**Checking Port** 

(O-ring)

## PNEUMATIC PULL CLAMPS

## R⇔₩S

imao



**Unclamping Port** 

(O-ring)

Part Number	d (F7)	D2	H (±0.01)	D	Hı	D1 (g6)	H4	H2	Dp *)	М	H₃	H₅
AMWPD40-W	8	40	40	75	38	50	15	30	63	M5×0.8	26	6
AMWPD63-W	12	63	50	105	47	75	19	35	88	Rc <sup>1</sup> /8	31	10

Part Number	Furnished O-ring	Operating Air Pressure (MPa)	Clamping Force (kN) **)	Weight (kg)
AMWPD40-W	D4	00.10	1	1.3
AMWPD63-W	P4	0.3~1.0	2.5	3.2

\*) The dimensions above are for ports with o-ring.


\*\*) The clamping forces above are at 0.5 MPa.

#### Feature

#### ■High Clamping Force

 Wedge mechanism increases clamping force to 200% compared to the air cylinder of the same size.
When the air pressure is lowered by such as an air leakage, wedge mechanism prevents prompt lowering of the clamping force. Clamping Force at 0 Mpa Air Pressure (by spring force)

#### ·AMWPD40-W···160N



#### **Technical Information**

Allowable Counterforce (Per Clamp)

Part Number	Max. load(N)		
AMWPD40-W			
AMWPD63-W	Clamping force $\times$ 2		

#### **Related Product**

- ·AMWPD-X CLAMPING PINS
- ·AMWPD-M CLAMPING SCREWS


#### 🖌 Note

•Use clean air by removing moisture and debris with an air dryer and air filter.


· Impurities in the compressed air can cause malfunction.

## Checking Hole

Can check if the workpiece is clamped properly by applying air through the checking hole.




#### **Performance Curve**




### How To Use

- ■How to Locate Workpiece
  - 1. Basic Method




2. Method for clamping and locating at a time Locating Accuracy  $\pm 0.08$ 



### How to Install

#### 1.With Side Ports

- ·Attach the furnished o-rings to the bottom ports.
- ·Plate surface must be flat( $\stackrel{6.3}{\searrow}$ )to get the bottom ports sealed up.
- ·Check if there is no air leakage from the area of the bottom ports.




#### 2.With Bottom Ports

- ·Attach the furnished o-rings to the bottom ports.
- •Plate surface must be flat  $(\frac{63}{\sqrt{}})$  to get the bottom ports sealed up.
- •Refer to the figure below for the hole details.

AMWPD40-W

·Ensure that the furnished air block plugs are attached to the side ports.



AMWPD63-W