

# BJ351-C

## COIL SPRINGS FOR CYLINDRICAL WORK SUPPORTS



Body
SWPA steel

### How To Use

Replacement springs to set the piston spring force lower.

Part Number	Piston Spring Force (N)	Cylindrical Work Supports
<b>BJ351-06001-C1</b>	3~ 7	BJ351-06001
<b>BJ351-08001-C1</b>	5~ 9	BJ351-08001
<b>BJ351-10001-C1</b>	5~ 9	BJ351-10001
<b>BJ351-12001-C1</b>	6~11	BJ351-12001
<b>BJ351-16001-C1</b>	7~14	BJ351-16001

