

QLSND-AN10

ANGLE ADAPTOR





Dedicated for Snap Clamps



IMA O



M6 Cap-Screw Hole




Cross Section X-X




Body
S45C steel
Black oxide finish

Part Number	Weight (g)
QLSND-AN10	12


Dimensions of Snap Clamps with Angular Adaptor Installed



QLSND



QLSNS28



QLSNS30

Type	H	L	H ₁	L ₁
QLSND28	130	57	71	84
QLSND30	145	61	79	92

Type	H	L	H ₁	L ₁	θ	θ ₁
QLSNS28	110	60	6	107	30°	50°
QLSNS30	136	53	2	123	35°	60°

Supplied With


Hex.socket head cap screw M6×1-12L × 1pc.

How To Use

Remove the handle and then install an Angular Adaptor between the body and the handle.
(Use a wrench of nominal size 9 for removal of the handle.)

Perfect in applications where the handle can not be turned to the clamping position.

Hex.Socket Head Cap Screw
M6×1-12L



Conflict

