BJ132-A

HOOK-CLAMP ASSEMBLIES

 $\frac{7}{4}$


Ξ


I

R⊕#S









| Clamp Body | Holder | | | | | |
|---|---|--|--|--|--|--|
| SCM440 steel Quenched and tempered Black oxide finished | S45C steel Quenched and tempered Black oxide finished | | | | | |

| Part Number | H ₁ | S (Clamping Stroke | W ₁ | М | L ₁ | R | D ₁ | Нз | M 1 | L | Н | D | W | H ₂ | W ₂ | Wз |
|--------------|----------------|--------------------------|-----------------------|--------|----------------|----|----------------|----|------------|----|----|----|----|----------------|----------------|----|
| BJ132-04018A | 35 | 3 | 8 | M4×0.7 | 14 | 18 | 14 | 35 | M6×1 | 11 | 45 | 14 | 8 | 7.5 | 3 | 12 |
| BJ132-06022A | 40 | 4 | 10 | M5×0.8 | 17 | 22 | 16 | 40 | M8×1.25 | 14 | 53 | 16 | 10 | 9.5 | 5 | 13 |

| Part Number | Clamping Force (kN) | Allowable Screw Torque (N·m) | Weight (g) | | |
|--------------|---------------------|------------------------------|------------|--|--|
| BJ132-04018A | 2 | 2.7 | 55 | | |
| BJ132-06022A | 3.5 | 7 | 90 | | |

Feature

The hook clamp is designed to move up and down in conjunction with the tightening screw, for prevention of galling in the hook-clamp holder.

How To Use

